



This PDF is generated from authoritative online content, and is provided for convenience only. This PDF cannot be used for legal purposes. For authoritative understanding of what is and is not supported, always use the online content. To copy code samples, always use the online content.

## Outbound Contact

tones Section

12/16/2025

## tones Section

- [busy-tone-1](#)
- [busy-tone-2](#)
- [disconnect-tone](#)
- [extra-dial-tone](#)
- [fax-tone-1](#)
- [fax-tone-2](#)
- [forth-tone](#)
- [intl-dial-tone](#)
- [local-dial-tone](#)
- [ring-back-tone-1](#)
- [ring-back-tone-2](#)
- [sit-tone](#)

This content is under development and might not be comprehensive or completely up to date. For full information, see [Configuration Options](#) in the *Deployment Guide*.

### busy-tone-1

**Default Value:** 500;200;0;0;55;40;55;40;4;

**Valid Values:** Any string of numbers separated by semicolons and representing the nine tone parameters.

**Changes Take Effect:** Takes effect immediately

Defines a template for the first busy tone.

### busy-tone-2

**Default Value:** 500;200;500;200;55;40;55;40;4;

**Valid Values:** Any string of numbers separated by semicolons and representing the nine tone parameters.

**Changes Take Effect:** Takes effect immediately

Defines a template for the second busy tone.

### disconnect-tone

**Default Value:** 500;200;500;200;55;40;55;40;10;

**Valid Values:** Any string of numbers separated by semicolons and representing the nine tone

parameters.

**Changes Take Effect:** Takes effect immediately

Defines a template for disconnect tone, also known as a 'fast busy tone'.

## extra-dial-tone

**Default Value:** 401;125;401;125;0;0;0;0;0;

**Valid Values:** Any string of numbers separated by semicolons and representing the nine tone parameters.

**Changes Take Effect:** Takes effect immediately

Defines a template for an extra dial tone.

## fax-tone-1

**Default Value:** 2150;150;0;0;25;-25;0;0;0;

**Valid Values:** Any string of numbers separated by semicolons and representing the nine tone parameters.

**Changes Take Effect:** Takes effect immediately

Defines a template for the first FAX tone.

## fax-tone-2

**Default Value:** 1100;50;0;0;25;-25;0;0;0;

**Valid Values:** Any string of numbers separated by semicolons and representing the nine tone parameters.

**Changes Take Effect:** Takes effect immediately

Defines a template for the second FAX tone.

## forth-tone

**Default Value:** 0;0;0;0;0

**Valid Values:** Format: Frequency of first tone (from 200 Hz to 4000 Hz); Frequency of second tone (from 200 Hz to 4000 Hz); Amplitude of first tone ( E1: -40 dBm0 to +0 dBm, T1: -43 dBm0 to -3 dBm); Amplitude of second tone ( E1: -40 dBm0 to +0 dBm, T1: -43 dBm0 to -3 dBm);Duration (10 millisecond increments)

**Changes Take Effect:** Takes effect immediately

The forth-tone option enables or disables a beep signal that alerts an agent immediately before a customer is connected to him or her. When an agent is in the engaged mode and waiting to be

connected to a customer, this lowfrequency tone notifies him or her that a connection is imminent. You can configure the tone frequency, duration, and amplitude of the signal. CPD Server supports this signal on DM3 hardware and SIP-HMP-ASM line-type.

## intl-dial-tone

**Default Value:** 402;125;402;125;0;0;0;0;0;

**Valid Values:** Any string of numbers separated by semicolons and representing the nine tone parameters.

**Changes Take Effect:** Takes effect immediately

Defines a template for an international dial tone.

## local-dial-tone

**Default Value:** 400;125;400;125;0;0;0;0;0;

**Valid Values:** Any string of numbers separated by semicolons and representing the nine tone parameters.

**Changes Take Effect:** Takes effect immediately

Defines a template for a local dial tone.

## ring-back-tone-1

**Default Value:** 450;150;0;0;130;105;580;415;0;

**Valid Values:** Any string of numbers separated by semicolons and representing the nine tone parameters.

**Changes Take Effect:** Takes effect immediately

This option defines a template for the first ring-back tone.

## ring-back-tone-2

**Default Value:** 450;150;450;150;130;105;580;415;0;

**Valid Values:** Any string of numbers separated by semicolons and representing the nine tone parameters.

**Changes Take Effect:** Takes effect immediately

This option defines a template for the second ring-back tone.

## sit-tone

**Default Value:** 900;1000;5;50;0;0;0;0;0;0;0;

**Valid Values:** Any string of numbers separated by semicolons and representing the nine tone parameters.

**Changes Take Effect:** Takes effect immediately

Defines the SIT signal parameters in the Dialogic DX\_CAP data structure.