



This PDF is generated from authoritative online content, and is provided for convenience only. This PDF cannot be used for legal purposes. For authoritative understanding of what is and is not supported, always use the online content. To copy code samples, always use the online content.

CSTA Connector for BroadSoft BroadWorks Deployment Guide

Keep-Alive Feature

12/17/2025

Keep-Alive Feature

CSTA Connector responds to Keep-Alive requests from the XSP link. CSTA Connector may not always receive timely notification when the XSP link stops functioning. In order for CSTA Connector to detect link failure and initialize alarm and recovery procedures, CSTA Connector usually needs to actively check the link's integrity. This is referred to as Keep-Alive or *KPL* functionality.

CSTA Connector sends BroadWorks KPL request on an established XSP link when the interval from the last message that is received from the XSP link is greater than the value specified by the **kpl-interval** configuration option. Setting the value of this option to 0 (zero) switches off any *active* KPL functionality.

For each KPL request, CSTA Connector expects to receive a BroadWorks `keepaliveResponse` message from the XSP link. The XSP link is considered as *unresponsive* when a number of missing KPL responses become greater than the value specified by the **kpl-tolerance** configuration option. Setting the value of the `kpl-tolerance` option to a value of 0 (zero) marks the link as unresponsive after a single KPL response goes missing.

CSTA Connector then closes the unresponsive link and tries to re-establish it by using the timeout value specified by the `link-recovery-tout` configuration option.