

GENESYS

This PDF is generated from authoritative online content, and is provided for convenience only. This PDF cannot be used for legal purposes. For authoritative understanding of what is and is not supported, always use the online content. To copy code samples, always use the online content.

GVP Documentation Supplement

Correction: <tt>bargein</tt> property's behavior with interpreters

Correction: **bargein** property's behavior with interpreters

SUMMARY: Behavior of the bargein property with GVP interpreters is missing from the VXML Help. (GVP-7433)

The next publication of the GVP 8.1 Voice XML Help will include this revision:

HELP TOPIC: Standard VoiceXML > Properties **SECTION:** Prompt and Collect Properties Barge-in **ADD THE RED TEXT** to the existing table row:

Property	Description	Default Value
bargein	Controls whether user input can be collected before prompts have finished playing: • true—Any user input can barge in during prompts. • false—No user input can barge in during prompts. How bargein interacts with interpreters In the legacy VoiceGenie interpreter, the application can set the value of the bargein property to dtmf. When this value is set, only DTMF input stops the prompt, whereas a start-of-speech that is detected by the speech recognizer does not. The Next Generation Interpreter (NGI) does not support this feature. In NGI, VCR controls are enabled even though bargein is set to true. For example, pressing 5 will pause audio that is playing.	true