



This PDF is generated from authoritative online content, and is provided for convenience only. This PDF cannot be used for legal purposes. For authoritative understanding of what is and is not supported, always use the online content. To copy code samples, always use the online content.

SIP Server Deployment Guide

Modifying the From Header in SIP INVITE

5/5/2025

Modifying the From Header in SIP INVITE

Contents

- [1 Modifying the From Header in SIP INVITE](#)
 - [1.1 DN-Level Configuration Options](#)

SIP Server provides the ability to modify the From header in outgoing SIP INVITE messages. Use the following configuration options to enable this functionality, depending on your needs.

DN-Level Configuration Options

These **cpn**-controlling options are configured on an Extension DN or VoIP Service DN with **service-type=softswitch**.

cpn-self

Setting: DN level > **[TServer]** section

Default Value: An empty string

Valid Values: Any string

Changes Take Effect: For the next call

If configured, SIP Server replaces the User-Name in the From header of the INVITE message with the value of this option, when sending the INVITE to the device/DN where this option is specified. This option takes precedence over any other **cpn**-controlling option and the CPNDigits key in AttributeExtensions of a T-Library request.

cpn-dnis

Setting: DN level > **[TServer]** section

Default Value: An empty string

Valid Values: Any string containing the name of the VoIP Service DN with **service-type=dial-plan**

Changes Take Effect: For the next call

If configured, SIP Server replaces the User-Name in the From header of the INVITE message with the value produced by applying dial-plan rules to the call DNIS, when sending the INVITE to the device/DN where this option is specified. This option applies only to inbound calls.

cpn-digits-to-both-legs

Setting: DN level > **[TServer]** section

Default Value: false

Valid Values: true, false

Changes Take Effect: For the next call

This option applies to a TMakeCall request containing the CPNDigits key-value pair in AttributeExtensions. If set to true, SIP Server replaces the User-Name in the From header of the INVITE message with the value of the CPNDigits, when sending the INVITEs to a call originator and a call destination.

Important

Genesys does not recommend using the **cpn** configuration option and the options described above together on the same device.